



### POWER SYSTEM

The Highball, Jackpot, Deuce, Double-Down and Double-Up vehicles are equipped with a 12V and 240V power system, to operate all appliances and features inside the vehicle. Each vehicle is installed with two batteries, one to start the engine and an auxiliary battery to power 12V items such as the refrigerator, internal lights and water pump. To engage the battery, the 12V isolator switch must be turned on and can remain on for your entire rental. To make sure your appliances, such as the refrigerator, continue to operate as expected, we recommend plugging into 240V power at a camping ground at least every 1-2 days. This will ensure your auxiliary battery holds an optimum charge. Your battery will recharge when driving, however this will never fully recharge the auxiliary battery. If you do not regularly plug your vehicle into a powered site, the auxiliary battery will flatten and your appliances will not operate, however you will still be able to start the engine and drive. It is important to note however that the Lowball's internal lights operate from the starter battery, so if left on for prolonged periods of time, you will drain your battery and not be able to start your engine.

When plugged into 240V power at a camping ground, you will be able to charge your vehicle's auxiliary battery and be able to operate 240V appliances such as the heater, microwave and power points. These items will not operate unless plugged into 240V power at a camping ground. To do this, you simply connect the power cable supplied in your vehicle, to the connection box at the camping ground. You must also ensure that the 240V circuit breakers are turned on.



### LPG GAS

There is an LPG bottle provided in Mighty vehicles to operate the cooker and hot water system (in some models). Mighty will provide you with a full LPG bottle on departure and recommend that you select our prepay LPG option, to save you the hassle of having to return it full on vehicle drop-off. Charges will apply if the bottle is not returned full, unless the prepaid LPG option has been taken. It is important that you turn your LPG bottle off before you drive.



### WATER

All Mighty vehicles have fresh water on-board. In most models, water can be accessed through the taps provided the water pump is switched on. It is important to ensure that your auxiliary battery has sufficient charge, otherwise your water pump may fail to operate. You should always switch off your water pump when it's not in use, to avoid draining your auxiliary battery and building up pressure in the water pipes. It is also important to keep your fresh water tank topped up. We recommend you do this every 1-2 days, using the fresh water hose provided. Ensure you fill your tank slowly to avoid air locks. There is an overflow vent, so once the tank is completely full, excess water will flow out from underneath the vehicle. The Deuce, Double-Down and Double-Up vehicles have an LPG water heater installed to allow you to enjoy warm showers. The water takes approximately 20 minutes to heat and will last for approximately 15 minutes, so short showers are recommended.



### WASTE WATER

In some Mighty vehicles the waste water or 'grey water' that runs through the drains in the shower and sink ends up in a holding tank. This should be emptied on a regular basis. It can be emptied into designated dump stations at camp sites. **It is an offence to dump any waste in a non-authorised location.**

We provide a waste water hose in your vehicle to allow you to easily drain your tank into an authorised dump station. We recommend that you empty your waste water tank daily or every time you fill your fresh water tank.



### TOILET

The toilet in the Deuce and Double-Up Mighty vehicles has a separate 19lt holding cassette and its own flush reservoir.

The cassette must be emptied into a public toilet or designated area. **It is an offence to dump any waste in a non-authorised location.**

Toilet chemicals will keep your cassette smelling fresh and can be purchased with us prior to your departure. We recommend that you empty your toilet cassette and refill the flush reservoir every 2-3 days.